
INSTRUCTION MANUAL

A) DISPLAYS AND BUTTONS



B) SETTING THE TIME

- 1. Pull the crown out to the 2nd position.
- 2. Turn the crown to set hour and minute hands.
- 3. After the time has been set, push the crown back to the Normal position.

C) SETTING THE DATE

- 1. Pull the crown out to the 1st position.
- 2. Turn the crown clockwise to set the date.
 - * If the date is set between the hours of around 9:00 PM and 3:00 AM, the date may not change on the following day.
- 3. After the date has been set, push the crown back to the Normal position.

D) USING THE CHRONOGRAPH

- 1. Press button "A" to start/ stop the chronograph.
- 2. Press button "B" to reset.
- *After 2 hours of continuous running, the chrono stops and resets automatically to save the battery.

Split time

- 1. Press button "B" while the chronograph is running.
- 2. Press button "B" again to return to the chronograph.
- 4. Press button "A" to finalize timing.
- 5. Press button "B" to reset.

E) CHRONOGRAPH RESET (INCL. AFTER REPLACING BATTERY)


After the battery has been replaced or mishandling only.

- 1. Pull the crown out to the 1st Position.
- 2. Press button "B" to reset minute counter. Each press of button "B" will advance the chronograph minute hand by one increment or press and hold button "B" for fast advance.
- 3. Press button "A" to reset 1/5 second counter. Each press of button "A" will advance the chronograph 1/5 second hand by one increment or press and hold button "A" for fast advance.
- 4. Push the crown back to the normal position.



8171/203R00

操作指引





時間設置

- 1. 將表冠拉出至位置"2"。
- 2. 轉動表冠、將時針和分針設置到所要的時間。
- 3. 將表冠按回原位。

日曆設置

- 1. 將表冠拉出至位置"1"。
- 2. 順時針轉動表冠設置日曆。
 - *如果日曆在晚上9時至零晨3時之間設置,日曆可能不會在下一天更改。
- 3. 將表冠按回原位。

計時器操作

- 1. 按下按鈕"A", 啟動/停止計時器。
- 2. 按下按鈕"B"歸零。
 - *連續運轉2小時後,計時器將自動停止並重設,以節省電池電量。

分段計時

- 1. 計時器運轉時,按下按鈕"B"。
- 2. 再次按下按鈕"B",即可返回計時器模式。
- 3. 按下按鈕"A"可結束計時。
- 4. 按下按鈕"B"歸零。

重設計時器(包括更換電池後)

應在重設計時碼表後記時秒針未返回到0秒位置時,以及更換電池後執行此步驟。

- 1. 將表冠拉出至位置"1"。
- 2. 按下按鈕"B"重設分鐘計數器。每按一次按鈕"B",計時器分針即會前進一個增量,按住按鈕"B"可使分針快速前進。
- 3. 按下按鈕"A"重設1/5秒鐘計數器。每按一次按鈕"A",計時器1/5秒針即會前進一個增量,按住按鈕"A"可使1/5秒針 快速前進。
- 4. 將表冠按回原位。

