



INSTRUCTION MANUAL

A) DISPLAYS AND BUTTONS



B) ADJUSTING DUAL TIME HANDS POSITION

- * After setting or changing the battery, before setting the time, check if the dual time hour hand is at the "0" (24 o'clock) position.
- * If the dual time hour hand is not at the "0" position, reset it following the procedure shown below :
 1. Pull out the crown to 1st position.
 2. Keep the buttons "A" & "B" pressed at the same time for more than 2 seconds, then release the buttons.
 - * Dual time hour hand moves and returns to where it was.
 3. Press button "A" or "B" to reset the dual time hour hand to "0" position.
 - * Button "A" : dual time hour hand moves counter-clockwise
 - * Button "B" : dual time hour hand moves clockwise
 - * The dual time hour hand moves quickly if the respective buttons are kept pressed.
 4. Push the crown back in the Normal position.

C) SETTING THE TIME

1. Pull out the crown to 1st position when the second hand is at the 12 o'clock position.
2. Turn the crown to set the hour and minute hands. (make sure 24 hour hand is set correctly).
3. Push the crown back in the Normal position.
 - * The 24 hour hand moves correspondingly with the hour hand.

D) SETTING THE DUAL TIME



[Quick set the dual time]

1. Crown at Normal position.
2. Adjust the time by pressing the button "A" or "B".
 - Button "A" : - 1 hour / push
 - Button "B" : +1 hour / push

[Precise adjustment of the the dual time]

1. Pull out the crown to 1st position when the second hand is at the 12 o'clock position.
2. Adjust the time by pressing the button "A" or "B".
 - Button "A" : -10 minute / push
 - Button "B" : +10 minute / push
3. Push the crown back in the Normal position.

操作指引



重新設定兩地時間指針位置

* 安裝電池後，請於設定時間之前檢查兩地時間時針是否指向"0" (24小時方向)。

* 如兩地時間時針並非指向"0"，循以下步驟重設：

1. 拔出表冠至位置"1"；
2. 同時按下按鈕"A"及"B"超過兩秒，然後放手；
* 兩地時間時針會移動，並回到原位；
3. 按下按鈕"A"或"B"以重設兩地時間時針至位置"0"；
* 按鈕"A"：指針逆時針方向移動
* 按鈕"B"：指針順時針方向移動
* 如按著相應的按鈕不放，指針會快速移動；
4. 將表冠按回原位。

時間設置

1. 秒針於12時位置時，拔出表冠至位置"1"；
2. 旋轉表冠以調校時針和分針至目標時間 (檢查24小時指針是否正確設定)；
3. 將表冠按回原位。
* 24小時指針與時針同步運作；

兩地時間設置

[簡易設定]

1. 表冠於原位；
2. 按下按鈕"A"或"B"以設定時間：
* 按鈕"A"：- 1小時 / 每次按動
* 按鈕"B"：+ 1小時 / 每次按動

[精確調校]

1. 秒針於12時位置時，拔出表冠至位置"1"；
2. 按下按鈕"A"或"B"以調校時間
* 按鈕"A"：- 10分鐘 / 每次按動
* 按鈕"B"：+ 10分鐘 / 每次按動
3. 將表冠按回原位。