



INSTRUCTION MANUAL

A) DISPLAYS AND BUTTONS



B) SETTING THE DATE

1. Pull the crown out to the 1st position.
2. Turn the crown clockwise to set the date.
 - * If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.
3. After the date has been set, push the crown back to the Normal position.

C) SETTING THE TIME

1. Pull the crown out to the 2nd position.
2. Turn the crown clockwise to set hour and minute hands.
3. After the time has been set, push the crown back to the Normal position.


D) SETTING THE DUAL TIME

Press button "A" to set the dual time hand forward in units of 15 minutes.

Press button "B" to set the dual time hand back in units of 15 minutes.

* The dual time hand can be set rapidly by continuously pressing button "A" or "B".

操作指引



日期設置

1. 將表冠拉出至位置"1"。
2. 順時針轉動表冠，調校日期。
 - * 如果日曆在晚上 9 時至 零晨1 時之間設置，日曆可能不會在下一天更改。
3. 將表冠按回原位。

時間設置

1. 將表冠拉出至位置"2"。
2. 順時針旋轉表冠，向前調整時針和分針。24小時指針將隨時針和分針移動。持續旋轉直至達到所需的時間。
3. 將表冠按回原位。

兩地時間設置

按鈕"A": 主控6時位小眼，以15分鐘為單位向前調整。

按鈕"B": 主控6時位小眼，以15分鐘為單位向後調整。