



INSTRUCTION MANUAL

A) DISPLAYS AND BUTTONS



*Date & crown position may be located at different position depends on models.




B) SETTING THE TIME

1. Pull the crown out to the 2nd position.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position, second hand begins to run.


C) SETTING THE DATE

1. Pull the crown out to the 1st position.
2. Turn the crown counter-clockwise to set the date.
 - * If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change the following day.
3. After the date has been set, push the crown back to the Normal position.

操作指引



*日曆和表冠可能位於不同位置需取決於型號。



時間設置

1. 將表冠拉出至位置"2"。
2. 轉動表冠、將時針和分針設置到所要的時間。
3. 將表冠按回原位。

日曆設置

1. 將表冠拉出至位置"1"。
2. 逆時針轉動表冠設置日曆。
* 如果日曆在晚上 9 時至 零晨1 時之間設置，日曆可能不會在下一天更改。
3. 將表冠按回原位。